




Bracket Dimensions - Ceiling Fix




SERIES 57 FINELINE
 Small Ceiling Fix Bracket No 5853
 Gliders 5832



SERIES 57 FINELINE
 Ceiling Fix Snap in Bracket No 5853L
 Gliders 5832




SERIES 57 FINELINE S-WAVE
 Small Ceiling Fix Bracket No 5853




SERIES 57 FINELINE S-WAVE
 Small Ceiling Fix Bracket No 5853



Bracket Dimensions - Face Fix




SERIES 57 FINELINE
Single Support Bracket No 5755
Gliders 5832



SERIES 57 FINELINE S-WAVE
Single Support Bracket No 5755

NOTE:
75mm for clear
pocket tape




SERIES 57 FINELINE
Double Support Bracket No 5755S

Series 57

Fineline Track




Bracket Dimensions - Face Fix



SERIES 57 FINELINE
Double Support Bracket No 7455S
Gliders 5832
NOT SUITABLE FOR DOUBLE S-WAVE

NOTE:
 75mm for clear
 pocket tape




NOTE:
 75mm for clear
 pocket tape

NOTE:
 75mm for clear
 pocket tape


SERIES 57 FINELINE S-WAVE
Double Support Bracket No 5755L



Bracket Dimensions - Face Fix




SERIES 57 FINELINE
Single Support Bracket No 5855
Gliders 5832



SERIES 57 FINELINE S-WAVE
Single Support Bracket No 5855

NOTE:
75mm for clear
pocket tape



SERIES 57 FINELINE
Double Support Bracket No 5855D
Gliders 5832

Series 57 Fineline Track



Bracket Dimensions - Face Fix

